

## Programming Quick Guide

**-DC9250D: Docking Scanner**


**-DC9260D: Wearable Scanner**

### Docking Scanner:


Gently tap the trigger area at the middle of scanner, to enable the scanner(for reading barcode)

### Wearable Scanner:

Press the ring trigger to enable the scanner.



The touch sensor area is around middle of the scanner as drawing shown.



### Installation

Before using scanner, please make sure that the OTG device is fully charged.

#### 1. Under USB HID interface

\*\* When plugged into OTG device, it will be recognized and begin to scan the barcode.

\*\* Open the APP first. The data you scan will be sent to cursor site directly.

#### 2. Under USB Serial interface

\*\* Please install PL-2303 driver into your OTG device first. PL-2303 driver can be downloaded from Google Play


\*\* Connect scanner to your OTG device, then, you can know which serial port scanner connects to.

\*\* The data you scan will be sent to serial port and your APP can get the data from serial port directly.

### Reset Configuration to Defaults

If you are unsure of the scanner configuration or have scanned the incorrect codes, please scan the "Default" barcode.

(scan from A1 to A6 for HID or B1 for RS232/USB Serial)



### Keyboard Country(For USB HID only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States:

@ | \$ # { } [ ] = / ' \ < > ~



USA

(Original setting)



Italian



Norway



France



Germany




Vietnam




Sweden



Spain




Denmark



Portugal



Switzerland



Hungary

## 1D Symbologies – 2

### Barcode Configuration Method:

Please follow the below 4 steps to complete the "Symbologies Enable" or "Symbologies Disable"

1. Start Configuration
2. Choose one of 1D Symbologies
3. Enable setting: scan Enable-1, then Enable-2  
Disable setting: scan Disable-1, then Disable-2
4. End Configuration

Start  
Configuration




### 1D Symbologies – 1

UPC-A



UPC-E



EAN-13  
(ISBN/ISSN)



EAN-8



Industrial  
2 of 5



Matrix  
2 of 5



Code 93



Code 11




MSI/Plessey



UK/Plessey




Codabar



Code 128




UCC/EAN 128



ISBT 128



Code 39  
(Code 32)



Interleaved  
2 of 5



China Post



GS1 DataBar



GS1 DataBar Limited



GS1 DataBar  
Expanded



Enable-1



Disable-1



Enable-2



Disable-2



End  
Configuration



- Information in this document is subject to change without notice.
- For more information, please visit:  
[www.riotec.com.tw](http://www.riotec.com.tw)