


Programming Quick Guide

-DC9257L: Docking Scanner

Docking Scanner:

Gently tap the trigger area at the middle of scanner, to enable the scanner(for reading barcode)

Docking Scanner



The touch sensor area is around middle of the scanner as drawing shown.




Installation

They are Plug & Play USB (HID) devices. When plugged into your Android OTG devices, it can be recognized as barcode scanner and begin to scan the barcode. Before using scanner, make sure the smartphone or tablet is fully charged. Open your APP, they can work as a keyboard input.


Reset Configuration to Default

(scan from 1 to 3)




Barcode Configuration Method:

(Flow chart for setup procedure :)




Keyboard Country (For USB HID only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | \$ # { } [] = / ' \ < > ~




Keyboard Country (For USB HID only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | \$ # { } [] = / ' \ < > ~




1D Symbolgies – 1




Barcode Configuration Method:


(Flow chart for setup procedure :)




1D Symbolologies – 2



1D Symbolologies – 3



2D Symbolologies



Inter-Keystroke Delay (For USB HID only)

This parameter specifies the delay between emulated keystrokes.



- Information in this document is subject to change without notice.
- For more information, please visit: www.riotec.com.tw